## **Rope Installation**

Remember, fencing should be configured in a manner such that all cattle are compelled to walk under the unit several times per day to reach water and/or shade. Furthermore, you may consider allowing the cattle several days to adapt to any new path and the presence of the unit before installing the ropes. To saturate the ropes, additional insecticide will be necessary during the first day of use.

1. Begin by inserting each end of one rope through the first two holes on the inside of the structural steel channel. You may need to use a regular size flat screw driver to help work the ends of the ropes through the holes in the steel channel. Exercise care to avoid

damaging the paint or the rope ends.





2. Pull the two rope ends until the flat side of the galvanized sleeve is near the inside bottom surface of the structural steel channel.

3. Continue with each pair of holes until all six ropes are installed.



If you have further questions, please contact:

Southern Agritech LLC Telephone: 386-362-5214 Email: ken@kencampbell.net